



- 1 - PROPORTIONING CAP WITH FEED ADJUSTMENT KNOB
- 2 - EZ-FLO SHUT OFF VALVES
- 3 - FILL AND DRAIN VALVES
- 4 - FERTILIZER OUT - CONNECT CLEAR TUBE TO GREEN CONNECTIONS ON PROPORTIONING CAP AND TO THE CONNECTION DOWNSTREAM FROM THE VALVE.
- 5 - WATER IN - CONNECT BLACK TUBE TO BLUE CONNECTIONS ON PROPORTIONING CAP AND TO THE CONNECTION UPSTREAM FROM THE VALVE
- 6 - TANK LEGS (INCLUDED) ATTACHED TO 4" X 4" WOOD BLOCK (NOT INCLUDED)
- 7 - MAIN LINE TO VALVE MANIFOLD
- 8 - UPSTREAM TAPPING CONNECTION TO MAIN LINE - 3/8" MINIMUM. POSITION A MINIMUM OF 2" UPSTREAM OF THE VALVE DISC WHEN IT IS IN THE OPEN POSITION.
- 9 - DOWNSTREAM TAPPING CONNECTION TO MAIN LINE - 3/8" MINIMUM. POSITION A MINIMUM OF 2" DOWNSTREAM OF THE VALVE DISC WHEN IT IS IN THE OPEN POSITION.
- 10 - MAIN LINE FROM BACK FLOW PREVENTER
- 11 - CEMENT OR COMPACTED GRAVEL BASE
- 12 - EZ-FLO MODEL EZ030-HC FERTILIZATION SYSTEM 36"L X 19"W X 25"H
- 13 - BUTTERFLY OR BALL VALVE

NOTE:  
 ITEMS 3, 4, 5, 6, 7 AND 8 ARE INCLUDED WITH THE EZ-FLO SYSTEM. ITEM 11 IS PURCHASED SEPARATELY.

EZ-FLO FERTILIZING SYSTEM  
 MODEL NUMBER - EZ030-HC  
 30 GALLON CAPACITY  
 VALVE TAPPING INSTALLATION  
 NOT TO SCALE